

Honda KeyProg v 3.0

Honda Keyprog v3.0 supports Honda cars and Acura with mechanical key since 2002 and "Keyless Start" system since 2012. The device has an operating mode switch "K-N", bi-color led and a sound emitter. Time recording of new key 60 to 120 second.



Supported vehicles:

Honda/Acura: from 2002 till 2018 MY.

Operating modes:

Modes switch:

"N" - work with the mechanical key.

"K" - work with "Keyless start" system.

Operation sequence:

Step-by-step instruction for mechanical key:

Supported systems : All modern IMMO systems from 2002 onwards.

Acura: RDX, ILX, TLX, RLX, CDX;

Honda: CRV (2002+), Civic (2005+), Accord (2002+), Pilot (2002+)



1. Set the switch to the "N" position;
2. Switch on the ignition, turn the key to position "ON".
3. Insert the programmer, the **red** led will light up, short beeps will sound;

Only one key must be in the car!!!

4. The **red** led went out + the beeps stopped -> Switch ignition to "ACC" position;
5. The **red** led lights up + the beeps sounds -> Turn the ignition to "ON" position;
6. The **red** led went out + the beeps stopped -> Switch ignition to "ACC" position;
7. The **red** led lights up + the beeps sounds -> Turn the ignition to "ON" position;
8. The **red** led went out + the beeps stopped -> Switch ignition to "ACC" position;
9. The **red** led lights up + the beeps sounds -> Turn the ignition to "ON" position";
10. Rising "Sweep" sound from low to high tone + **green** led -> The key is recorded!
11. Switch off the ignition. You can start the engine and use the car.

*If you hear a downward "Sweep" sound from high to low, this means that the key is not recorded.
You need to check the suitability of the key and the car operability.*



WE RECOMMEND USING ONLY NEW ORIGINAL KEY !

NOT working with OLD immo system (RED KEY) !



Step-by-step instruction for “KeyLess Start” system:

Supported systems: Honda/Acura IMMO systems from 2012 onwards.

Honda: Civic (2014+), CRV (2015+)



1. Set the switch to the “K” position;
2. Switch on the ignition, turn the key to position "ON".
3. Insert the programmer, the **red** led will light up, short beeps will sound;
4. Press and hold the button until the steering lock is unblocked. The start button will flash **green**, the ignition will be activated;

Only one “KeyLess Start” key must be in the car !!!

5. The **red** led went out + the beeps stopped -> Switch off the ignition (Press “Start/Stop” button once);
6. The **red** led lights up + the beeps sounds -> Switch on the ignition (Press “Start/Stop” button twice);
7. The **red** led went out + the beeps stopped -> Switch off the ignition (Press “Start/Stop” button once);
8. The **red** led lights up + the beeps sounds -> Switch on the ignition (Press “Start/Stop” button twice);
9. The **red** led went out + the beeps stopped -> Switch off the ignition (Press “Start/Stop” button once);
10. The **red** led lights up + the beeps sounds -> Switch on the ignition (Press “Start/Stop” button twice);
11. Rising “Sweep” sound from low to high tone + **green** led -> The key recorded!
12. Switch off the ignition. You can start the engine and use the car.

***If you hear a downward “Sweep” sound from high to low, this means that the key is not recorded.
You need to check the suitability of the key and the car operability.***



WE RECOMMEND USING ONLY NEW ORIGINAL KEY!

TO PURCHASE THE EQUIPMENT, AS WELL AS CONSULTING, MAINTENANCE,

PLEASE CONTACT US:

Url: <http://www.autodevice.net>

Email: info@autodevice.net